


# Smart Cat Feeder F3 Camera



User Manual



## Dear Pet Lovers:

Thanks for purchasing our Smart Pet Feeder.



We want to walk into the pets life together with you and offer what pets really need.

To have a better user experience, please read the manual carefully and kindly keep it for further reference.

Scan the QR code and follow our  
Facebook, through which you would get high  
quality after-sales services



# Meet Your Smart Cat Feeder



## Install Petwant Application

Method one: Scan the following QR code and download the APP follow the instruction in download page.

Method two: iOS user can enter the APP Store and enter "Petwant" to download it. Android user can enter the Google Store and enter "Petwant" to download it.



Petwant



### Notice

1. QR Code download is suggested.
2. Please allow network access and location access for normally using.

## Register Your Account

Method one: Enter Petwant APP and click "Register" to apply an account.

Method two: Log in through the third-party like Wechat, Facebook, Twitter etc. (Fig. 1) .

## Choose Your Device

Choose your feeder model to get configuration (Fig. 2) .

Note: One device can only bind to one account, but one account can be used on multiple phones.




Fig. 1




Fig. 2

## Preparing the connection (Please make sure your mobile device has been connected to your Wi-Fi network)

1. Plug in the power adapter and from the bottom of the smart feeder, switch the unit on.
2. Wait for the power indicator to turn on.
3. Hold the "SET" button on the control panel of the smart feeder until you hear a Chime.
4. The green indicator should be quick flashing (Fig. 3) .

# AP Mode Connection

- 1. If the smart phone was connected to the Wi-Fi, then you need to click "Next".
  - 2. Enter the Wi-Fi Password (Fig. 4) .
- If your Wi-Fi name does not appear, please return to the previous step and ensure you are connected before proceeding.




Fig. 3



Fig. 4

# QR Mode Connection

Make the QR code close to the camera within 10 cm to identify, you can hear a chime if identified successfully. Please click "Heard" to Fig. 5.

If you can not hear anything within 5-10S through the QR mode connection, please click "Can't hear sound" to Fig. 6.



Fig. 5




Fig. 6

## AP Mode Connection

(The green link indicator should be quick flashing)

1. Fig 7 will appear, click next.
2. You will be taken to the Wi-Fi connection page.
3. Choose the Smart Feeder Connection "PETWANT\_XXXXXX" (Fig. 8).
4. Return to the APP Android devices, return directly to the APP rather than re-launching from the main menu (use the recently used APP menu, or click the arrow at the top left of the screen) iOS devices, return to the APP from the link on the top left corner of the screen.

Note: Once connected to the device's Wi-Fi, to return to the APP, do not relaunch the APP from the home screen, use the back arrow, or the recently used apps menu to return to the application.




Fig. 7



Fig. 8

# Linking the Smartphone and Pet Feeder

The previous steps connected the Smart Feeder and the Smartphone to the Wi-Fi. Now you will connect the Smartphone to the Smart Feeder.

- 1. Click next.
- 2. The link will begin (Fig. 9).
- 3. Click done to complete the connection (Fig. 10).



Fig. 9




Fig. 10



## Complete the Connection

Click done to Petwant the connection when the linking progress reach to 100%.  
Enter Petwant APP Interface (Fig. 11).





Fig. 11

## APP Interface

More settings



# Scheduling Automatic Feeding

- 1. From the main APP interface swipe to the left and you will see the "Manual Feeding" option. This allows you to instantly feed your pet (Fig.12 ).
- 2. Hold your finger down on the Manual Feeding circle.
- 3. Click icon to select portion size (Fig.13 ).
- 4. Alternatively you can hold the "SET" button on the Smart Feeder to dispense the food instantly.




Fig. 12




Fig. 13

# Scheduling Automatic Feeding

You can set 4 automatic scheduled feeding times.

1. Click "+" from the main APP interface to set portions, personalized recording and the timing for regularly scheduled feeding, then click done (Fig. 14).
2. To delete a scheduled time, click and hold the time, once the box pops up, select delete (Fig. 15).




Fig. 14




Fig. 15

# Instant Feeding

- 1. From the main APP interface swipe to the left and you will see the "Manual Feeding" option. This allows you to instantly feed your pets.
- 2. Hold your finger down on the Manual Feeding circle (Fig. 16).
- 3. Click icon to select portion size.
- 4. Alternatively you can hold the set button on the feeder to dispense food instantly (Fig. 17).




Fig. 16




Fig. 17

# Talk and Listen

Click the video from the main APP interface, and now you can listen, record, speak to, and see your pets from anywhere in the world.



\*You can click Talk and Listen at the same time to open the "Two-way Interaction", the default setting is "One-way Communication" (Talk or Listen).

# Pet Information

Name

Age

Breed

Weight

Character

You have been with  
Petwant for

0 day

Manual

0 times

0 portion

Auto

0 times

0 portion

Total

0 times

0 portion

More than  
users worldwide

0%

VIDEO

FEEDING

PET

# Other Settings

Device Management and Time Zone setting.

Manage your recordings.

View a log of events, from successful feedings to indicators of no food under device management (Fig. 18).

Motivation Detection Sensitivity (Fig. 19).




Fig. 18





Fig. 19



## Assembly & Disassembly

### ASSEMBLING AND DISASSEMBLING THE FEEDER:


Hold both sides of the food bucket and lift upwards for removal;  
The direction of the food bucket gears need to be aligned with the direction of the main body slot. Once aligned, press downward.



### ASSEMBLING THE FOOD TRAY

Hold the feeder slightly backwards and fit the tray into the opening below. Push it towards the body.

\* The metal tray also lifts out for easy cleaning.



### ⚠ Cleaning Your Smart Feeder

1. Please turn off and unplug the device before cleaning.
2. Clean the unit with a damp cloth rather than a soaked cloth.
3. The food tray and tank can be removed for cleaning in an automatic dishwasher.
4. The base cannot be immersed in water at any time or it may cause a short circuit of the device.

## Important Safety Information

Proper safety warning information can avoid potential danger for people and pets. Please read the safety information carefully.

1. Fit for small animals.
2. Do not use outdoors. For indoor ( household ) only.
3. Do not disassemble the feeder's components except the food tray and food tank.
4. Do not place anything on top of the feeder.
5. The feeder is suitable for operation by users over 12 years old.
6. Do not disassemble or repair the feeder privately, if there is any malfunction or damage for the feeder, please contact our customer service team.
7. The feeder is suited for 0.2 - 0.6 inch diameter dry pet food. Do not put others thing into the feeder except pet food.
8. Please ensure feeder is properly plugged in to ensure adequate power before a long trip.
9. If the plug of this device gets wet, turn off the electricity to the wall outlet, do not unplug. If there is damage around the power cord or adapter, please contact our customer service team.
10. To avoid electric shock, do not place the power cord or plug near water or other liquids, only use power cord that is sold by the manufacturer.
11. Do not immerse the feeder in water at any time, the pet feeder shouldn not be submerged in water at any time, otherwise the electric components will be damaged.
12. Dispose of all packaging materials properly, some components may be packed in poly bags, these bags could cause suffocation; Keep away from children and pets.
13. Examine this appliance after installation, do not plug in if there is water on the power cord or plug. To avoid tipping, please place the device against a wall.
14. This product is for use by pets, any accidents caused by unauthorized usage is invalid. We will not be responsible for unauthorized usage.