Quick start guide.

litter-robot by whisker





Scan to access our online setup guide (including tips to acclimate your cat), the user manual, and accessory installation guides, or visit litter-robot.com/aettingstarted



- If possible, place the Litter-Robot in the same location as the old litter box (at least during transition).
- Make sure the unit is indoors on a firm, level surface and in a cool, dry location. Must not be touching any walls.
- Place litter mats or rugs in front of the unit.



- Use clumping litter or litter beads and crystals that are small enough to pass through the screen.
- Add litter until it meets the raised MAX fill line when spread flat (8-10 lbs or 3.6-4.5 kg). Be careful not to overfill.





Dlug tk

Plug the small end of the power supply into the power input on the back of the base. 9

Plug the AC/DC adapter into a wall outlet.

0

Press the Power button on the control panel.

0

Download the **Whisker app** and follow the onboarding instructions.





The Litter-Robot will now perform an initial clean cycle.

Note: During initial clean cycle, the cat sensor weight scale is disabled to ensure proper calibration.

Need help? Visit whiskersupport.com

Control panel icons



Power

- Press the Power button to turn the robot ON or OFF.
- The robot will begin a clean cycle when power is turned on.



Cycle

- Press the Cycle button to start a clean cycle.
- A long press, while at the home position, will enter sleep mode.
- If already cycling, press Cycle to pause; press again to resume a cycle.



Reset

- Press the Reset button to zero the weight scale.
- A long press, while at the home position, will enter night light setting mode.
- If already cycling, press Reset to pause a cycle; press again to cancel a cycle.
- If already cycling, a long press will reset the cat sensor weight scale.



Empty

- Press the Empty button to start an empty cycle.
- A long press, while at the home position, will enter wait time setting mode.
- If already cycling, press Empty to pause.



Connect

- Press the Connect button to turn the WiFi ON or OFF.
- A long press, while at the home position, will initiate the onboarding process.



What do the lights mean?



Solid Blue

Robot ready and connected



Solid Yellow

Robot paused during cycle

Press Cycle button to continue cycling



Flashing Blue

Waste drawer full





Round Robin Yellow*

Robot cycling

*Yellow light moving with the rotation of the globe



Solid Blue WiFi Flashing Yellow

Robot in WiFi onboarding mode





Solid Red

Cat detected and wait time countdown initiated

No action required or press Reset to cancel timing



Solid Purple

Sleep mode enabled, within specified sleep time